

INSTALLATION ADAPTER EP-013J EZ-GO ST-480

SAFETY WARNING

1. ALWAYS WEAR EYE PROTECTION.
2. PLACE DIRECTIONAL SWITCH IN NEUTRAL.
3. PLACE KEY SWITCH IN THE OFF POSITION.
4. SET PARKING BRAKE.

INSTALLATION INSTRUCTIONS

1. LIFT CART UNTIL TIRES ARE 2" OFF GROUND.
2. PLACE BLOCKS OR STANDS UNDER CART AND REMOVE JACK.
3. REMOVE FRONT BUMPER
4. ADAPTER MOUNTS BETWEEN AXLE AND RACK AND PINION STEERING UNIT SEE PIC BELOW.
5. EXTRA HARDWARE WAS ADDED TO REPLACE SOME OF THE HARDWARE ON THE CART.
6. (3 EA) LONG SPACERS THESE ARE FOR THE STEERING HOUSING MOUNTING HOLES.
7. (6 EA) CAP SCREWS 7/16 X 1 3/4" LONG THESE ARE FOR THE PASSENGER SIDE FRONT SPRING MOUNT HOLES AND THE DRIVER SIDE SPRING MOUNT HOLES REPLACING THE 7/16 X 1 1/2" CAP SCREWS.

